



MODEL B SCHEMATIC



Model B Part Identification List

Part Number	Description
PN 17	Shock Cord
PN 23	Travelling Pulley
PN 30	Front Leg Assembly
PN 31	Rear Leg Assembly
PN 32	Heel Rest
PN 64	Seat Frame
PN 82	Shock Cord Pulley
PN 113	Straight Arm
PN 114	Bent Arm
PN 117	Left Footboard
PN 118	Right Footboard
PN 253	Fancage Bolt
PN 236	Monitor Bumper (for PM1 only)
PN 123	Heel Rest Bolt
PN 124	Heel Rest Wing Nut
PN 125	Heel Rest Washer
PN 126	4-1/2" Frame Bolt
PN 127	5" Frame Bolt
PN 128	Frame Bolt Nut
PN 135	Handle Hook
PN 136	Handle Hook Cover
PN 164	S.C.A.M.
PN 167	Handle Grip
PN 184	Chain Connector w/Cover
PN 185	Chain Slide
PN 215	Skewer Screw
PN 240	Handle U-Bolt Nut
PN 241	Monorail
PN 244	Handle U-Bolt
PN 277	Skewer Assembly (everything inside monorail)
PN 279	Handle Assembly
PN 280	Chain w/Connector/Swivel
PN 378	Seat Roller w/Hardware
PN 383	Leg U-Bolt
PN 384	Leg U-Bolt Nut
PN 417	Flywheel Cage (Flywheel Assembly no longer available)
PN 585	Seat Top w/Frame and Screws
PN 1044	Molded Foot Cap
PN 1207	Seat Screw
PN 1501	Footstraps
PN 1881	PM3 Monitor for Model B (PM1 and PM2 no longer available)
PN 1929	Seat Top w/Screws

Common Parts not shown on Schematic

PN 265	Monitor Pickup w/Cable
PN 276	Chain Guard
PN 381	Footboard Screw
PN 382	Footboard Nut
PN 485	Sprockets
PN 1246	Seat Screw Washers